

Advanced Sensor Technologies, Inc.

TEL: 714-978-2837 TOLL FREE: 1-888-WOW-ASTI (969-2784) FAX: 714-978-6339

IMPORTANT NOTES FOR AMMONIUM ISE SYSTEM

Calibration and Cleaning of Ammonium Selective Ion Measurement System For Waste Water Ammonium Analysis

- | All calibration solutions and Process Grab Sample should be calibrated and tested at identical temperatures to the process temperature. The actual temperature of the process solution (and thereby the calibrating solutions as well) is not as critical as the fact that they are calibrated at the same temperature. For greatest overall accuracy of the ammonium (NH_4^+) measurement, however, measurement should be performed as close to 25 degrees Celsius (room temperature process solutions) as possible.
- | Calibration Point 1 (always the lower concentration value) and Calibration Point 2 (always the higher concentration value) determines the response of the 54e Analyzer to a given Ammonium Ion Selective Sensor (AB 6410 & AB 8410). The calibration solutions values for Calibration Point 1 is 1.00 ppm and Calibration Point 2 is 10 ppm
- | The One Point Re-Calibration Standard (usually a process grab sample or one of the two ammonium standard solution) is always performed by using the standardize option from the Calibrate Main Menu. A one point calibration should never be performed by using the 2-point calibration option from the Calibrate Main Menu.
- | At all times the calibration solutions should be kept clean and out of direct sunlight and/or other high-energy radiation sources. New sensors should be conditioned in ammonium standard solution for 3 - 5 minutes before beginning calibration procedure as described in this quick calibration guide.
- | The acceptable pH range of the AB 6410 & AB 8410 Ammonium Sensor is 2.5 – 9.0. For continuous long-term use, ASTI recommends a pH less than 7.0 to eliminate the need for compensation of the pH effects on ammonium concentration. At pH levels above 7.0, the ammonium sensor will not detect the total ammonia content, as some of the ammonium ion will be converted into the form of dissolved ammonia gas. See the attached pH dependent dissociation curve for ammonia gas & ammonium ion.
- | To enter custom ion menu, hold F3 for 5-7 seconds, then enter secret code of 20000 into system.

The following steps are required for an installation of a new ammonium sensor:

- 1) Enter the nominal ISO Voltage (+ 140 mV) and Slope (+ 59.16 mV per decade) as given on the proceeding page.
- 2) Perform a two point calibration to empirically determine slope. See attached procedures for 2-point calibration.
- 3) Perform a one-point calibration (standardize) at the defined (expected) measurement value. This value is 1 ppm NH_4^+ for this measurement. Use the 1 ppm Ammonium Standard Provided by ASTI. See the proceeding section one point calibration for further details on use of this calibration function.
- 4) Place sensor into process and allow to find equilibrium.
- 5) To account for any differences between the ionic strength and interfering ions between calibration and measured solution, a grab sample should be taken and analyzed by an alternate analysis system, and the online Ammonium system adjusted to read the analyzed value. The sensor should be left in process and this grab sample calibration performed as may be required, unless the sensor seems to be losing sensitivity or giving erratic readings.

603 North Poplar Street Orange CA 92868-1011 USA

General inquiries e-mail: information@astisensor.com

Inside Sales e-mail: sales@astisensor.com

Web Site: <http://www.astisensor.com>

Advanced Sensor Technologies, Inc.

TEL: 714-978-2837 TOLL FREE: 1-888-WOW-ASTI (969-2784) FAX: 714-978-6339

MENU for ROSEMOUNT 54e AMMONIUM ANALYZER

| Setting / Value Column | Function / Parameter Column |
|--|---|
| Main Sub-Menu | Calibrate Main Menu ----- |
| Calibrate Sub-Menu | 2-Point Calibration |
| 1.00 ppm | Calibration Point 1 (Factory Defined – DO NOT MODIFY) |
| 10 ppm | Calibration Point 2 (Factory Defined – DO NOT MODIFY) |
| Enabled | Hold Option for Outputs 1 & 2: Read Rosemount 54e-pH/ORP Manual for Details |
| Calibrate Sub-Menu | Standardize |
| Variable | Standardize Concentration: Value = Grab Sample, Calibration Solution 1 or 2: See calibration instructions for details on this function; a.k.a. 1-point calibration |
| Calibrate Sub-Menu | Adjust Temp |
| User Defined | Manual Adjustment of temperature, not required for most installations |
| Calibrate Sub-Menu | Temp Compensation |
| <i>Setting / Value</i> | <i>FUNCTION / PARAMETER</i> |
| Manual 25°C | Temperature Compensation (Factory Defined – DO NOT MODIFY) |
| Main Sub-Menu | Diagnostic Variables ----- |
| Defined by 54e | Displays all currently defined variables in 54e Memory |
| Main Sub-Menu | Program ----- |
| Program Sub-Menu | Alarm Setpoints |
| Rosemount Default 0.000 ppm & 999.9 ppm | Variable alarm setpoints for 3 @ relays Any user defined value within measurement output range is acceptable |
| Program Sub-Menu | Output Setpoints |
| 4mA= 0.000 ppm 20mA = 100 ppm | 4-20mA Output 1 – Process Ammonium ISE These are only the factory defaults. These values can be altered. |
| 90 seconds | Time Average of Process Output |
| 4mA= 5°C 20mA = 40°C | 4-20mA Output 2 – Temperature These are only the factory defaults. These values can be altered. |
| 20 seconds | Time Average of Temperature Output |
| Program Sub-Menu | Diagnostics |
| Disabled | Disabled diagnostics required to make Ammonium ISE measurement run properly (Factory Defined – DO NOT MODIFY) |
| Program Sub-Menu | Simulated Test |
| Rosemount Default | Read Rosemount 54e-pH/ORP Manual for Details |
| Program Sub-Menu | Configure |
| ASTI Programmed Passcode for Configure | Passcode to enter Configure Function is 974. Various parameters in this function may affect output and display of Analyzer |
| NH ₄ ⁺ | Selective Ion Measurement Parameter (Factory Defined – DO NOT MODIFY) |
| ppm | Display units for NH ₄ ⁺ Measurement (Defined in Program-Configure Menu) |
| °C | Display units for Temperature Measurement (Defined in Program-Configure Menu) |
| -999 to + 999 | ISE Input Range in mV's – Rosemount Defined |
| Custom Ion Curve | Press F3 for 5-7 seconds, enter Passcode of 20000 |
| 18.00 grams per mol | IONIC WEIGHT (Defined by Selective Ion Measurement – DO NOT MODIFY) |
| 1440 ppm (1.0969) | ISOPOTENTIAL CONCENTRATION (Factory Defined – DO NOT MODIFY) |
| + 59.16 mV per decade | DEFAULT SLOPE (Will be changed when 2-point calibration is performed) |
| + 140 mV | ISOPOTENTIAL VOLTAGE (Will be changed when 2-point calibration is performed) |

603 North Poplar Street Orange CA 92868-1011 USA

General inquiries e-mail: information@astisensor.com

Inside Sales e-mail: sales@astisensor.com

Web Site: <http://www.astisensor.com>

Advanced Sensor Technologies, Inc.

TEL: 714-978-2837 TOLL FREE: 1-888-WOW-ASTI (969-2784) FAX: 714-978-6339

Ammonium (NH₄⁺) Probe Two Point Calibration

This calibration method should not need to be performed frequently. All new ammonium sensors should be calibrated using a 2-point calibration first. Subsequent calibrations can be made using only the standardize option from the Calibrate Main Menu. This calibration determines the sensitivity or slope of each sensor, which is then stored in the 54e transmitter. A “standardize” (a.k.a. 1-point) calibration must be performed after every 2-point calibration. Details for the 1-point calibration are given in the proceeding page. **MAKE SURE THAT THE “HOLD” FEATURE IS ON BEFORE STARTING ANY CALIBRATION. READ THE ROSEMOUNT 54E-PH/ORP MANUAL FOR FURTHER DETAILS ABOUT THE HOLD FEATURE.**

Set-up requirements:

- Two 250 mL GLASS OR PLASTIC BEAKERS.
- Low Ammonium Standard Solution (1.00 ppm)
- High Ammonium Standard Solution (10 ppm)

Standard ammonium solutions are provided by ASTI. These standard solutions are re-ordered by indicating the special part numbers or notes (if any) that appear on the calibrating solution bottles. Do not dilute or in any other way modify these standardization solutions. Keep ammonium solutions out of direct sunlight or any other radiation source.

Follow the on-screen directions in 2-point calibration submenu in the 54e Analyzer. Calibration Points 1 & 2 have been preprogrammed into your instrument. The low standard solution (1.00 ppm) will always be Calibration Point 1 & the high standard solution (10 ppm) will always be Calibration Point 2. Do not change the preprogrammed values for Calibration Point 1 & 2.

Important Notes about Calibration:

- Fill a 250 mL GLASS beaker with enough standardization solution such that the entire tip of the ammonium sensor will be submersed
- Please read the attached sheet on the cleaning procedure for this ion selective sensor. The cleaning procedure should usually be performed when transferring a sensor in or out of solution. Sensors can also be cleaned before being placed into different concentration standardization solutions and/or grab sample solutions. Cleaning is only required if fouling appears on the ISE membrane or on the reference junction. If no contamination is apparent, then the simple rinsing procedure given below can be used.
- Thoroughly rinse the sensors with DI water and gently blot dry with a clean paper towel. Be careful not to scratch or damage the sensitive organic ammonium ion selective membrane
- Allow a minimum of 3 – 5 minutes for the sensor to stabilize once it has been removed from the process and placed into the low standard solution (1.00 ppm).
- Allow a minimum of 3 – 5 minutes for the sensor to stabilize between the low and high Calibration Solutions (1.00 ppm to 10.0 ppm).

Key Sequence for 2-Point Calibration

1. Press any Function Key
2. Highlight Calibrate and Enter Function
3. Select Hold Mode to On and Continue
4. Select 2-Point Calibration and Enter Function
5. Ammonium sensor should be in 1.00 ppm standard solution already cleaned and conditioned. Press Continue. Instrument will display that Calibration Point 1 is stabilizing. The instrument will take about 20 seconds to stabilize and determine mV value for the first calibration point.
6. After Cal Point 1 has stabilized select edit and input 1.00 ppm into instrument. **This value must be entered even if it already is correct on the display.** After 1.00 ppm has been entered into Analyzer, press save to continue to second calibration point.
7. Ammonium sensor should be in 10 ppm standard solution already cleaned and conditioned. Press Continue. Instrument will display that Calibration Point 2 is stabilizing. The instrument will take about 20 seconds to stabilize and determine mV value for the second calibration point.
8. After Cal Point 2 has stabilized select edit and input 10 ppm into instrument. **This value must be entered even if it already is correct on the display.** After 10 ppm has been entered into Analyzer, press save.

THE ROSEMOUNT ANALYZER AT THIS POINT SHOULD DISPLAY “2-POINT CALIBRATION DONE”. ONLY IF THIS MESSAGE APPEARS HAS THE TWO-POINT CALIBRATION BEEN SUCCESSFULLY PERFORMED, OTHERWISE REPEATED STEPS AS OUTLINED ABOVE UNTIL THE ANALYZER ACCEPTS THE TWO-POINT CALIBRATION.

603 North Poplar Street Orange CA 92868-1011 USA
General inquiries e-mail: information@astisensor.com
Inside Sales e-mail: sales@astisensor.com
Web Site: <http://www.astisensor.com>

Advanced Sensor Technologies, Inc.

TEL: 714-978-2837 TOLL FREE: 1-888-WOW-ASTI (969-2784) FAX: 714-978-6339

Single Point Calibration –

This is the correct method to Adjust for Sensor Drift

Ammonium Sensor One Point Calibration

- Only use the “Standardize” function from the Calibrate Menu. Any other method will destroy the previous 2-point calibration
- Can be performed DAILY if required.

When the ammonium system has been calibrated by the 2-point method it can then be used in the “single point” calibration mode (on a daily basis if required). **MAKE SURE THAT THE “HOLD” FEATURE IS ON BEFORE STARTING ANY CALIBRATION. READ THE ROSEMOUNT 54E-PH/ORP MANUAL FOR FURTHER DETAILS ABOUT THE HOLD FEATURE.**

Set-up requirements:

- Two 250 mL GLASS OR PLASTIC BEAKERS
- Low Ammonium Standard Solution (1.00 ppm) or
- High Ammonium Standard Solution (10 ppm) or
- Process Grab Sample Solution

Follow the on-screen directions in the “Standardize” submenu of the Calibration Menu in the 54e Analyzer. No value has been preprogrammed into your instrument for the standardization concentration. Both the low and high standardization solutions can be used to perform the “1-point” calibration performed by the standardize function. In addition, grab samples can be taken from the process and analyzed by an alternate method for ion concentration. The separately determined concentration of the process sample can then be entered into the standardize menu. In this way, the ammonium sensor can be standardized without ever having to remove the sensor from the process line.

Important Notes about 1-point “Standardize” Calibration:

- Fill a 250 mL GLASS beaker with enough standardization solution such that the entire tip of the ammonium sensor will be submersed
- Read the attached sheet on the cleaning procedure for this ion selective sensor. The cleaning procedure should usually be performed when transferring a sensor in or out of solution. Sensors can also be cleaned before being placed into different concentration standardization solutions and/or grab sample solutions. Cleaning is only required if fouling appears on the ISE membrane or on the reference junction. If no contamination is apparent, then the simple rinsing procedure given below can be used.
- Thoroughly rinse the sensors with DI water and gently blot dry with a clean paper towel. Be careful not to scratch or damage the sensitive organic ammonium ion selective membrane
- Allow a minimum of 3 – 5 minutes for the sensor to stabilize once it has been removed from the tank and placed into either the low or high standard solution.

Key Sequence for 1-Point Calibration

1. Press any Function Key
2. Highlight Calibrate and Enter Function
3. Select Hold Mode to On and Continue
4. Select Standardize and Enter Function
5. Ammonium sensor should be in 1.00 ppm standard solution already cleaned and conditioned. Allow reading to stabilize. Press Edit. Enter 1.00 ppm into Analyzer and press save. The one point calibration is now complete. The reading on the display should be same as the entered standardize value. Alternatively, the 10 ppm calibration solution can be used for 1-point calibration if this is expected measurement value. If a grab sample is used, allow the sensor to find a stable reading in process. Enter the analyzed value of the process solution for the ammonium concentration. The sensor should be left in service while this standardize calibration is performed.

Advanced Sensor Technologies, Inc.

TEL: 714-978-2837 TOLL FREE: 1-888-WOW-ASTI (969-2784) FAX: 714-978-6339

Cleaning and Maintenance of ASTI " NH₄⁺" Probe

Before a major 2-point calibration the sensor may need to be cleaned each time. The frequency of cleaning will depend on the quality of the process water and the build up of process reagents on the probe tip.

Note:

Any noticeable deposits on the tip of the sensor will result in a less accurate calibration and measurement.

CLEANING:

1. Thoroughly rinse the sensor tip with DI water. Gently blot the sensor tip dry.
2. Scrape the entire Kynar reference area clean with a sharp blade or Stanley knife. This reference is solid Kynar and cannot be damaged. Do not scratch the membrane.
3. Once this has been achieved the entire tip can be soaked in either the low or high standardization solution. After allowing sufficient time for conditioning; proceed to perform a 2-point or 1-point calibration.
4. The standardization solutions can always be used as conditioning solution for extended storage. Do not allow sensor to be exposed to air for prolonged periods of time. Always store sensor in standardization solution when not in service in process. For long-term storage, a standard solution should be placed into sensor protective cap. The cap should be sealed onto sensor body with Teflon tape.

Advanced Sensor Technologies, Inc.

TEL: 714-978-2837 TOLL FREE: 1-888-WOW-ASTI (969-2784) FAX: 714-978-6339

Miscellaneous

| The decimal place can be moved in any screen of the 54e Analyzer by placing the cursor over the decimal place and using the up and down arrows to move the decimal point to any position.

| Do not to allow air bubbles to get trapped near the ammonium ion selective organic membrane. This is will cause erroneous readings and drift.

| The ammonium sensor is comprised of a high-impedance organic membrane system. Care should be taken not to move or touch the cable once a value is being stabilized. Touching the sensor cable can cause a noisy signal that may result in erroneous values and calibrations.

| Please see the hook-up schematic found in the AB 6410 & 8410 ammonium sensor shipping box, together with the specification sheet. Be sure to check whether that the jumper in the instrument is set for an internal preamplifier (preamplifier in analyzer setting).